

Read and save this document carefully!



Installation Instructions

User manual

10 Button remote

Well Straler
Industrielaan 22
9320 Erembodegem
info@wellstraler.be
www.wellstraler.be

Made in Belgium



Table of Contents

- 1 Operation of your Appliance..... 3
 - 1.1 Learn Remote Control Signal to Receiver 3
 - 1.2 Set up Fahrenheit or Celsius 4
 - 1.3 Set up Day and Time 4
 - 1.4 Child Lock..... 4
 - 1.5 Manual Mode 5
 - 1.6 Set Flame Height 5
 - 1.7 Set Low Fire 5
 - 1.8 Set High Fire 6
 - 1.9 Shutting off the Appliance..... 6
 - 1.10 Countdown Timer..... 6
 - 1.11 Operating Modes 7
 - 1.12 Thermostatic Mode..... 8
 - 1.13 Program Mode..... 8
 - 1.14 Eco Mode "Eco Wave" 11
 - 1.15 Double / single burner 11
 - 1.16 Fan..... 11
 - 1.17 Verlichting dimmer 12
 - 1.18 Operation by an External Source 12
 - 1.19 My Fire App..... 13
 - 1.20 Automatic Reduction of the Appliance 14
 - 1.21 Automatic Shutdown 14
 - 1.22 Replacing the Batteries..... 14
 - 1.22.1 Remote control..... 14
 - 1.22.2 External battery holder..... 15
- 2 Failure codes 16


1 Operation of your Appliance

1.1 Learn Remote Control Signal to Receiver



Make sure that batteries are present in the remote control and the receiver is powered.

The receiver must be learned to the remote control. Synchronizing between the receiver and the remote control must be done only on first use.

Press and hold the receiver's reset key (see picture receiver) until you hear two beeps. Unleash the reset key when hearing a second longer beep. In the next 20 seconds, press the button  of the remote control.

Two short beeps will confirm that the code is set. "COM" appears on the remote control to confirm that the synchronization has been performed (see picture remote control). At the end of the synchronization, the current status of the gas fireplace is displayed on the remote control.



Remote control



Receiver




Both the receiver and the remote control will send and receive signals (bi-directional). The remote control and receiver synchronize status information every 10 seconds for the first 2 minutes thereafter every 4 to 6 minutes to 1 hour. Pressing a button on the remote control activates an instant synchronization.




The synchronization is a one-time setting. It is not required after re-inserting new batteries in the remote control or the receiver.





Metal in the vicinity of the receiver can significantly reduce the reception.



1.2 Set up Fahrenheit or Celsius

















To switch between °C and °F, press simultaneously on the buttons  and .



When you choose °F, a 12-hour clock (AM/PM) appears. When you choose °C, a 24-hour clock is displayed.

1.3 Set up Day and Time




1. Press the buttons  and  simultaneously. The **day** will blink.
2. Press the button  or  to select the number corresponding to the day of the week (1 = Monday, 2 = Tuesday, 3 = Wednesday, 4 = Thursday, 5 = Friday, 6 = Saturday, 7 = Sunday)
3. Press the buttons  and  simultaneously. The **Hour** will blink.
4. To select the hour, press the button  or .
5. Press the buttons  and  simultaneously. The **Minutes** will Blink.
6. To select the minutes, press the button  or .
7. To confirm, press the buttons the  and  simultaneously or wait.

1.4 Child Lock






Enable:

To activate: press the buttons  and  simultaneously.


 is displayed and the remote control will no longer be able to be operated (unless the Child lock is turned off).

Disable:

To deactivate: press the buttons  and  Simultaneously.  disappears.

1.5 Manual Mode




1. Press the button  until you hear two short beeps and see a series of lines blinking. This means that the ignite process has started.


2. Release the button.


The gas from the burner will begin to flow once the pilot flame is ignited. The remote control automatically switches to manual mode after the main burner is ignited.

(See 1.22 for two button ignition)

1.6 Set Flame Height





To increase the flame, press the button  and hold it down.


To reduce the flame or set the appliance to the pilot flame, press the button on the  and hold it down.

1.7 Set Low Fire




 To unlock the "**low position**" and the "**high position**" double-click so the backlight of the remote control lights up.

For the **Low position** double-click on the  button.
LO Appears.

 The flame is raised first and then goes to the low position.

1.8 Set High Fire




For the **High position** double-click on the  button.
HI Appears.

1.9 Shutting off the Appliance




Press the  button to switch off.

 You must wait at least 5 minutes before reigniting the appliance.









 **SYSTEM OVERRIDE SHUTOFF**

If the fire will not Shutoff by pressing the power button, press and hold the power button for 12 seconds to shut the fire off .


1.10 Countdown Timer





Set up:

1. Press the button  and keep it pressed until  appears and the **Hours** will blink
2. To select the hour, press the button  or .
3. Press the button  to confirm. The **Minutes** will blink.
4. To select the minutes, press the button  or .
5. To confirm, press the button  or wait.

Shut off:


Press the button .

 and the countdown timer disappears.

 After the countdown time expires, the appliance is turned off. The countdown timer only works in the modes **Manually**, **Thermostatic** And **Eco**. The maximal countdown time is 9 hours and 50 minutes.

1.11 Operating Modes

Thermostatic mode:




The room temperature is measured and compared with the temperature set. The flame height is then automatically adjusted to reach the set temperature.

Program mode:




Programs 1 and 2 can both be programmed to enable and disable them at specific times at a set temperature.

Eco Wave:



The flame height alternates between high and low. If the room temperature is lower than the temperature set, the flame stays high for a longer period of time. If the room temperature is higher than the temperature set, the flame stays low for a longer period of time. A cycle takes about 20 minutes.

1.12 Thermostatic Mode



Set up:

Press the button .

will appear and the set temperature will shortly appear, after this the room temperature will be shown.

Shut off:


1. Press the button .
2. Press the button or to select the **Manual mode**.
3. Press the button to select the **Program mode**.
4. Press the button to select the **Eco mode**.



Setting temperature:

1. Press the button and hold until Appears.
The **Temperature** will blink.
2. To adjust the temperature, press the button on the or .
3. To confirm, press the button or wait.


1.13 Program Mode








Set up:

Press the button .

, 1 or 2, **ON** or **Off** will appear.




Shut off:








1. Press the button  or  or  to select the **Manual mode**.
2. Press the button  to select the **Thermostatic mode**.
3. Press the button  to select the **Eco mode**.



The set temperature for the **Thermostatic mode** is the temperature for the power-on time in the **Program mode**. When you set the temperature in the **Thermostatic mode** you also change the temperature for the power-on time in the **Program mode**.




Setting temperature:




1. Press the button  and press and hold it until  blinks. **ON** and the set temperature (set in thermostatic mode) will appear.
2. To continue, press the button  or wait. , **Off** appears and the temperature blinks.
3. Select the power off temperature by pressing the  or .
4. Press the button  to confirm.




The set temperatures for the switch-on temperature (thermostatic) and shut off temperature are the same for every day.




Set Day:

5. **ALL** blinks.
- Press the button  or  to choose between **ALL, SA: SU, 1, 2, 3, 4, 5, 6, 7**. (1 = Monday, 2 = Tuesday,...)
6. Press the button  to confirm.



Set up time ("ALL")

7. , **1** , **ON** will appear **ALL** appears momentarily and the **Hours** will blink.
8. To select the hour, press the button or .
9. Press the button to confirm.
 , **1** , **ON** appear **ALL** appears momentarily and the **Minutes** will blink.
10. To select the minutes, press the button Or .
11. Press the button to confirm.



Set the shutdown time ("ALL")

12. , **1** , **Off** appears **ALL** appears momentarily and the **Hours** will blink.
13. To select the hour, press the button or .
14. Press the button to confirm.
 , **1** , **Off** appears **ALL** appears momentarily and the **Minutes** blink.
15. To select the minutes, press the button or .
16. Press the button to confirm.



You can proceed to Programme 2 and set the set up and shut off times for the second period, or stop programming program 2 is then deactivated.



Program 1 and 2 use the same switch-on (thermostatic) and shutoff temperatures for ALL, SA: SU and (1,2,3,4, 5, 6, 7). As soon as a new switch-on (thermostatic) and/or shutoff temperature is set, this temperature becomes the new standard temperature.



If ALL, SA: SU or a day are programmed for the switching on and off times of Program 1 and Program 2, these are the new default times. To change the timings and temperatures for switching on and off Program 1 and Program 2 You must remove the batteries.


SA: SU or Day timer (1, 2, 3, 4, 5, 6, 7) selected:

The power-on/off time are the same for all days of the week follow the procedure as "ALL Selected"(above).


SA: SU: Set the power on and off time for both Saturday and Sunday.

Good bye Timer: You can set individual power-on and off times for one weekday, for several weekdays, or for all weekdays. Wait to finish the setting.

1.14 Eco Mode "Eco Wave"




Set up:

Press the button  to select the **Eco mode**.

 appears.

Shut off:


Press the button .

 disappears.

1.15 Double / single burner



If applicable



Set up:

To switch on the double burner, press the button .

 appears.

Shut off:


To switch to single burner, press the button .

 disappears.

1.16 Fan





If applicable





The circulation fan has four speeds ranges from low (1 bar) to high (4 bars).

Set up:

1. Press  and hold to  flashes.

2. Press  to increase the fan speed button  to reduce the fan speed.

3. To confirm the setting, press the button  or wait until  stops flashing.




The fan will automatically start 4 minutes after ignition at maximum speed, and will go to the last set level after 10 seconds. The fan will stop 10 minutes after turning off the gas or switching to the pilot. The fan can never be completely switched off, to prevent overheating of the electronics.

1.17 Verlichting dimmer



Not applicable



Set up: Press the button .

appears.

The lighting is set to a preset level.

Shut off: Press the button .

disappears.

Adjust: Press and hold the button until flashes.

To set the lighting between 20...100 %, press the or button.

To confirm the setting, press the button or wait until appears.



The lighting works separately from the pilot flame. If you want to turn on the lights but not the pilot light, press the button .

1.18 Operation by an External Source

The appliance can be operated by an external source, such as an automation system, via a connection to the receiver. The total length of the cable (available in option (Ref 27020)) can be up to 8 meters.

Ignition:

Close contact 1 and 3 simultaneously for 1 second.

High fire:


Close contact 1. The contact must be closed for 12 seconds to turn the motor of the gas block from end stop to end.

Low fire/Pilot Flame:

Close contact 3. The contact must be closed for 12 seconds to turn the gas block from end stop to end.

Shut off:

Close contacts 1,2 and 3 simultaneously for 1 second.




Possible operation modes:

- **Mode 1:** The external source has only an **On/Off** control. The remote control controls all other functions.
- **Mode 2:** The external source controls the room temperature. The remote control must be on **Manual mode**. If the remote control is set to the **Thermostatic mode** the remote control will have priority over the external source.

1.19 My Fire App


The appliance can be operated with a smartphone by means of the **MY FIRE APP**.


 before the app can be put into use, a **Wi-Fi Kit** needs to be connected to the receiver.



If the **Thermostatic, Program or Eco mode** is on, the corresponding icon is displayed and **APP** appears on the remote control.


The modes can be operated in accordance with the descriptions in the user manual of the **MyFire Wi-Fi Box**.


 **ADIM / VIEW:** Always place the MyFire Wi-Fi box upside down in the compartment at the bottom of the appliance to prevent the Wi-Fi box from overheating.



MyFire Wi-Fi Box

Compartment

 **A2:** Always place the MyFire Wi-Fi box next to the receiver under the protective cover to prevent the Wi-Fi box from overheating.



1.20 Automatic Reduction of the Appliance

No communication for 3 Hours:

Manual mode/thermostatic Mode/Program mode: The gas valve switches the flame over to the pilot flame if the flame height has not been altered for 3 hours. The fireplace will function normally once the communication has been restored.

Receiver Overheat:

All modes: The gas valve switches the flame over to the pilot flame if the temperature in the receiver exceeds 60°C. The main burner will only burn again if the temperature drops below 60°C.

1.21 Automatic Shutdown

Batteries Receiver:

If the batteries in the receiver are low, the system shuts off the appliance completely.

Extinguish of the pilot flame after longer inactivity:

This ecological function stops the gas consumption by automatically disabling the pilot flame when the appliance is inactive for a longer period of time. Due to this, the gas consumption can be reduced and therefore the costs can be reduced.

1.22 Replacing the Batteries

1.22.1 Remote control

- Slide open the rear end of the remote control.
- Remove the old batteries and place 2 new **AAA** batteries. Avoid short circuits between batteries and metal objects.
- Make attention to the "+" and "-" poles of the batteries and the holder.
- Use alkaline batteries.
- Close the lid.



ONE BUTTON AND TWO BUTTON IGNITION

Change from one button (default setting) to two button ignition or vice versa by pressing and holding the power button for 10 sec. immediately after installing batteries. ON is displayed and 1 or 2 (One or Two Button Ignition) is flashing. When change is complete 1 changes to 2 or vice versa.

1.22.2 External battery holder

- When installing the gas fire, place the battery holder in an easily accessible place.
- Slide open the battery compartment at the bottom.
- Remove and insert 4 AA batteries. Avoid short circuits between the batteries and metal objects.
- Pay attention to the “+” and “-” poles of the batteries and holder.
- Use alkaline batteries.
- Slide the lid back on.
- The battery holder has an ON/OFF switch, when using the fire this must always be set to ON.




When installing the gas fire, the batteries must be placed in the external battery holder! Regardless of whether the gas fire is already supplied with mains power with a mains cord.



The batteries should always be replaced during the annual maintenance of the gas fire!



Batteries are covered by "small chemical waste" and should not be disposed with the garbage.



2 Failure codes

Failure code	Display duration	Symptom	Possible cause
F04	4 sec.	<ul style="list-style-type: none"> • No pilot flame within 30 sec.. • NOTE: after 3 failed ignition sequences F06 shown 	<ul style="list-style-type: none"> • No gas supply • Air in pilot supply line • No spark • Reversed polarity in thermocouple wiring
F06	4 sec.	<ul style="list-style-type: none"> • 3 failed ignition sequences within 5 minutes • Fire is not responding; no pilot flame 	<ul style="list-style-type: none"> • No gas supply • Air in pilot supply line • No spark • Reversed polarity in thermocouple wiring • Check for correct pilot orifice (LPG to NG or vice versa)
F07	Until batteries are replaced	<ul style="list-style-type: none"> • Battery icon flashes on handset display 	<ul style="list-style-type: none"> • Low battery power in handset
F09	4 sec.	<ul style="list-style-type: none"> • Fire is not responding • No electronic control of fire 	<ul style="list-style-type: none"> • Down arrow button was not pressed during pairing • Receiver and handset are not synced
F46	4 sec.	<ul style="list-style-type: none"> • Fire is not responding • Intermittent response • No electronic control of fire 	<ul style="list-style-type: none"> • No or bad connection between Receiver and handset • No power at receiver (batteries low) • Low communication range (mains adaptor faulty, handset not communicating with receiver)